


HM 5G6



Part Code	Description	Specification	Qty
001	Main Blade 1		2
002	Balance Shaft Cover		2
003	Balance Block		2
004	Flybar Rod		1
005	Flybar Joint		1
006	Ball Linkage 1		1
007	Ball Linkage End		6
008	Flybar Rod Plastic Holder		1
009	Main Blade 2		2
010	Pin		4
011	Main Blade Holder		2
012	Cross Recessed Countersunk Flat Head Screw	KB1*3.5	7
013	Bearing	Φ1*Φ3*1	2
014	Small Shaft		1
015	Long Linkage		2
016	T-Shape Holder		1
017	Steel Ball		1
018	Inner Swashplate		1
019	Bearing	Φ6*Φ10*2.5	1
020	Outer Swashplate		1
021	Steering Frame		1
022	Locking Sleeve		1
023	Tail Rotor		1
024	Cross Recessed Countersunk Flat Head Screw	KB1*6	1
025	Tail Truss 1		1
026	Tail Truss 2		1
027	3g Servo		2
028	Main Frame		1
029	Skid Landing Holder		1
030	Screw With Washer	PWM1.4*3	4
031	Battery		1
032	Skid Landing		1
033	Upper Main Gear		1
034	Lower Main Gear		1
035	Cross Recessed Pan Head Screw	PM1.2*2.5	1
036	Small Shaft Locking Sleeve		1
037	Motor Main Gear		2
038	Skid Landing Cover		2
039	Canopy		1
040	Receiver		1
041	Canopy Rod Cap		2
042	Canopy Rod		1
043	Ball Linkage 2		2
044	Tapping Screw With Washer	PWB1.7*3	2
045	Servo Bellcrank		2
046	Motor		2
047	Bearing	Φ3*Φ6*2	2
048	Cross Recessed Countersunk Flat Head Screw	KB1*4	1
049	Cross Recessed Countersunk Flat Head Screw	KB1*2	5
050	Hollow Shaft		1
051	Swashplate		1